



- 1) Disconnect all power to the unit before opening the front cover.
- 2) Open the front cover and remove the divider panel to access the power interface board.
- 3) Install one end of the 2-conductor cable **40-06488-144** through the conduit fitting in the bottom of the unit, and connect to the far right, "Sensor 2" connections on the power interface board. Red wire to left, black wire to right, as shown.
- 4) Connect the other end of the cable to the 10096829 rinse probe assembly using the crimp-on spade connectors. Attach the two smaller connectors to the rinse probe wires, and the two larger connectors to the 2-conductor cable. (Polarity is not important)
- 5) Verify that the daughter board on the right, directly above the "Sensor 2" connection, is properly installed.
- 6) Replace the divider panel and close the front cover.

